

User's Manual

TS-6310

Features:


- Low voltage indication available on handheld microphone transmitter
- Circuit controlled switching noise avoidance

Operational Instructions:

Microphone:

- Handheld Microphone: Rotate the battery cover anti-clockwise, and put a 9V battery into the battery compartment with proper polarities, then rotate the battery cover clockwise till it is tight enough.
 - Belt-pack Transmitter: Open the battery cover by pressing the "OPEN" sign, then put in the batteries. (Caution: the battery must be in Correct Polarities
- Push the microphone power switch to the "ON" position. If the power indicator doesn't light, please check if the battery is full enough or the battery polarities are correct.
- If the mute function is needed, please push the switch to the middle position, then the microphone will be in mute state and the unit is still working.
- 4. When not using the microphone for a long time, please take out the batteries from the microphone base in order to avoid damaging the unit By chemical leakage from the battery.

Working Principle of Microphone:



Specification:

Modulation Mode: FM Transmit Power: ≤10mW Max Adjust Degree: ±20kHz

Transmitter Power Supply: 9V Battery

FCC WARNING

This device complies with Part 74 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: The manufacturer is not responsible for any changes or modifications not expressly approved by the manufacturer for compliance, such modifications could void the user's authority to operate the equipment.

NOTE 2: This device complied with FCC radiation exposure limits as set forth for an uscontrolled environment. This device should be installed and operated so that its antenna(s) are not co-located or operating in conjunction with any other antenna or transmitter